

CARE AND MAINTENANCE GUIDE

Phonitura products are highly durable and require minimal maintenance. Regular, gentle cleaning helps preserve their appearance and extends the life of the material.

Treat stains as soon as possible. Blot away liquids and carefully remove any hardened residue. Do not rub the surface forcefully.

RECOMMENDED

- Remove stains and dirt promptly by blotting with a clean, damp cloth or sponge.
- To remove dust, gently wipe the product with a dry microfibre cloth.
- If necessary, use a vacuum cleaner at low suction with a smooth attachment.

NOT RECOMMENDED

- Do not use abrasive sponges or cloths.
- Do not apply excessive pressure or rub the surface vigorously.
- Do not use harsh or aggressive cleaning liquids.
- Do not use washing-up liquids or laundry detergents.

CONTACTS

Phonitura
Email: info@phonitura.com